

Maxi and Sceptre trunking – continued

Material

PVC-U is flame retardant and self-extinguishing. It provides a 100% recyclable material with good sustainability.

Installation

Positioning


Feeder or distribution trunking.

Expansion/contraction

PVC-U expands and contracts at a uniform rate of approx 5.25mm in a 3 metre length for a temperature change of 25°C. Therefore, a 3mm gap between each length of trunking base is recommended. Fittings allow for thermal expansion of the covers.

Fitting

- Secure trunking base in one plane only every 500mm by drilling alternate 6mm holes.
- Use roundhead screws.
- Avoid over-tightening to permit thermal movement.
- The use of plastic caps over screw heads is recommended to protect installed cables.
- To provide cable segregation, dividing fillets are snapped on to internal ribs in base.
- To cut the trunking, use a fine-toothed panel or power jig-saw.
- External profile fittings overlap joints by up to 10mm to cover cutting inaccuracies.
- A variable angle jig-saw or chop saw is recommended for cutting 45° mitres.
- Maxi only:** trunking lengths are connected using internal couplers as follows:
 - Cement one end of the internal coupler to one base using adhesive solvent MSC. Leave other end of coupler free in adjoining base to facilitate thermal movement.




Single lengths

Where it is required to fit a single length of trunking (under 3 metres) between two inside walls and no accessory box is fitted, it is advisable to install a coupler in the centre of the run to facilitate the removal of the cover.

Joints and bends

- Clip-on fittings and 2-part moulded flat angle: base must be mitred at 45° to ensure total enclosure of trunking, including any internal fitted segregator.
- Fabricated fittings: a 3mm gap between trunking base and bend or flat angle is recommended.
- External moulded fittings overlap the joints by up to 10mm to cover cutting inaccuracies.
- Maxi fabricated fittings are supplied with internal couplers (see Fittings)
- Secure end caps using solvent adhesive MSC3.



Accessories

- Sceptre DTR1, Maxi MTRS100/50 and MTRS100:** accessory boxes and plates can be used.
- Remove appropriate knockout and clip box into base.
- Sceptre DTR2:** only accessory plates can be used.
- When boxes or plates are installed consecutively, fit a 25mm cover spacer (MTRS100LID25WH) between the accessories to conceal space between the boxes.

Covers

Covers are designed to limit unauthorised removal and to remain in position during normal conditions irrespective of impact and minor undulations of the mounting surface.

Covers – fitting

Covers are clipped into place from front. If accessory boxes are installed, the cover is butt-joined to the edge of the box. Cut edges of the cover are concealed by the accessory. For external fitting couplers, the following gaps should be left between the two cover ends to permit the fitting to clip to base:

DTR2	20mm
MTRS50	20mm
MTRS75	20mm
MTRS75/50	20mm
MTRS100/50	20mm
MTRS100	30mm

DTR1: DTR1 couplers are held in place by the two covers. To install, slide coupler up against first installed cover. Fit adjoining cover and slide up to coupler, ensuring the coupler moulding extends over the two covers.

Covers removal

To remove a cover, first detach a coupler or internal/external bend to gain access. The main cover can then be gently eased off the base.