

NCATAK KIT ACCESSORIES Quick Reference

For detailed instruction, please refer to NCATAK complete manual.

NCATAK - Kit Content

- Controller & PSU c/w battery backup (NCATAKC)
- Reset Point (NCATAKRP)
- Pull Cord c/w 3mtr cord and Triangle (NCATAKPC)
- Over door Light and Sounder (NCATAKOL)
- WC Toilet Sticker



NCATAKC



NCATAKPC




NCATAKRP



NCATAKOL

Installation



NCATAK KIT ACCESSORIES Quick Reference

For detailed instruction, please refer to NCATAK complete manual.

NCATAK - Kit Content

- Controller & PSU c/w battery backup (NCATAKC)
- Reset Point (NCATAKRP)
- Pull Cord c/w 3mtr cord and Triangle (NCATAKPC)
- Over door Light and Sounder (NCATAKOL)
- WC Toilet Sticker




NCATAKC



NCATAKPC




NCATAKRP




NCATAKOL


Installation



Connections



Controller Accept Button Selectable Options



Controller: LED & Buzzer Status

	AC LED	Battery LED	Buzzer
AC ON, Battery ok and Installed	ON	ON	-
AC ON, Battery low or not installed	ON	Flash every 60s	Tone every 60s
AC OFF, Battery ok and Installed	OFF	OFF	-
AC OFF, Battery low	OFF	OFF	Tone every 60s

For detailed instruction, please refer to NCATAK complete manual.

Distributed by:


FIRESAFE

10 Sandersons Way, Blackpool, FY4 4NB


Email sales@firesafe.co.uk

Website: www.firesafe.co.uk

Connections



Controller Accept Button Selectable Options



Controller: LED & Buzzer Status

	AC LED	Battery LED	Buzzer
AC ON, Battery ok and Installed	ON	ON	-
AC ON, Battery low or not installed	ON	Flash every 60s	Tone every 60s
AC OFF, Battery ok and Installed	OFF	OFF	-
AC OFF, Battery low	OFF	OFF	Tone every 60s

For detailed instruction, please refer to NCATAK complete manual.

Distributed by:

FIRESAFE

10 Sandersons Way, Blackpool, FY4 4NB

Email sales@firesafe.co.uk

Website: www.firesafe.co.uk