

Technical Characteristics

Wiser Sensors



Download

Wiser by SE app







The Wiser Window/Door Sensor detects opened and closed windows and doors, and reports the status to the Wiser Hub. It consists of two separate parts: a sensor and magnet. The sensor includes a circuit which detects the magnet when it is in close proximity. When the sensor is connected to the Wiser Hub and the window/door is opened or closed, the sensor reports the change to the Wiser Hub.



Wiser Window/Door Sensor

Identification	
Commercial reference	CLP591011
Product or component type	Sensor
Product colour	White
Power	
Operating voltage	3 V DC (1 lithium button cell battery CR 2450)
Battery life	Up to 5 years (may vary based on the usage, frequency of firmware update and environment)
Environment	
IP rating	IP20
Operating temperature	-10 °C to 50 °C
Operating humidity	10 % to 95 % RH, non-condensing
Installation	
Dimensions (H × W × D)	Sensor: 50 × 33 × 16.3 mm Magnet: 50 × 9 × 9 mm
Installation method	On window and door frames, with screws or adhesive pads
Package content	Sensor, battery (pre-inserted), sensor, magnet, mounting base plate, double-sided adhesive pads, 2 screws, and 2 wall plugs.
Certification	
Zigbee®	Zigbee 3.0

Dimensions (mm)



Note:

Download the Wiser by SE app to your smartphone, and install the Wiser Hub to configure and control Wiser devices. You can use the app to pair, set up and control Wiser devices. The Wiser by SE app is available in the App stores for smartphones supporting operating systems Android™ OS (version 7 and above) or Apple® iOS (version 11 and above).

For more detailed information, refer to the on-line system user guide. Scan the QR code or follow the link:
<https://www.productinfo.schneider-electric.com/clipsal/>

