


## CableCheck - Electrical fault indicator

(2 AAA batteries included)



INSTRUCTIONS

The electrical fault indicator detects any breakage in the heating cable during installation (open or short circuit).

Connect the electrical fault indicator to the free end of the cold lead of the heating cable and leave it on until the cable is completely embedded and protected.