



Einhell

PROFESSIONAL



Cordless Earth Auger

GP-EA 18/150 Li BL-Solo

Item No.: 3437000

Ident No.: 21010

Bar Code: 4006825659023

The cordless auger GP-EA 18/150 Li BL-Solo is a member of the Power X-Change family. The cordless device is delivered including the auger (80 cm length / 15 cm diameter). The durable brushless motor optimally converts the power to the thread. The auger is adjustable to 3 different modes: 1) Anticlockwise to release the drill 2) Clockwise in ECO mode. Regular power setting for light drilling tasks in soft ground & 3) Clockwise in HIGH power mode. Maximum power setting for hard surfaces. The robust metal frame offers maximum stability. Battery and charger are not included. These are available separately. An 18 V PXC battery is also required for operation.

Features & Benefits


- Member of the Power X-Change family, 1x18V batteries necessary
- Brushless motor - more power and longer runtime
- Metal frame - maximum stability and torsional stiffness
- 3 different modes: anticlockwise, clockwise: ECO & HIGH POWER
- Earth auger (80cm length / 15cm diameter) included in delivery
- Durable and robust gearbox integrated in aluminium housing
- Double handle with softgrip for ergonomic working
- Recommended for perfect results: 2,5Ah battery and bigger
- Supplied without battery and charger (available separately)

Technical Data

- | | |
|-------------------|-----------------------|
| - No-load speed | 125 min ⁻¹ |
| - Auger diameter | 150 mm |
| - Length of drill | 800 mm |

Logistic Data

- | | |
|--|---------------------|
| - Product weight (kg) | 6.01 |
| - Gross weight (kg) | 8.3 |
| - Dimensions single packaging | 1120 x 213 x 432 mm |
| - Pieces per export carton | 2 Pieces |
| - Gross weight of export carton | 19 kg |
| - Dimensions export carton | 1420 x 450 x 235 mm |
| - Container quantities (20"/40"/40"HC) | 384 760 892 |



BRUSHLESS



METAL FRAME



3 MODES




INCL.



18 V



**BEST
PERFORMANCE
WITH
≥ 2.5 Ah**



BRUSHLESS

Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Mortar Stirrer (Earth Auger)
Earth Auger Accessory
Item No.: 3437011
Bar Code: 4006825659047
Einhell Accessory



120mm Earth Auger
Earth Auger Accessory
Item No.: 3437010
Bar Code: 4006825659030
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



1m Extension (Earth Auger)
Earth Auger Accessory
Item No.: 3437012
Bar Code: 4006825659054
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	earth drilling ¹ (pieces)
1.5 Ah	10
2.0 Ah	15
2.5 Ah	20
3.0 Ah	30
4.0 Ah	40
5.2 Ah	50
6.0 Ah	60
8.0 Ah	80

Test setup:

1) Step 2