



Einhell

PROFESSIONAL



Cordless Paint/Mortar Mixer

TP-MX 18-2 Li BL - Solo

Item No.: 4258770

Ident No.: 21012

Bar Code: 4006825667639

Part of the Power X-Change family, the Einhell Professional cordless paint and mortar stirrer TP-MX 18-2 Li BL Solo is the perfect device for mixing concrete, plaster, levelling compound, mortar or paint. The low-maintenance brushless motor and 2-speed transmission ensure maximum performance. The cordless stirrer is equipped with a speed control to adapt to the consistency or degree of hardness of the mixture. The softstart avoids paint splashes and the swirling up of powders. The ergonomic handle with softgrip ensures a comfortable grip. The stirrer adapter is equipped with an M14 thread. Delivery includes a stirrer (Ø 120 mm) and an open-end spanner. Delivery does not include battery or charger.

Features & Benefits


- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor - more power and longer running time
- PurePOWER Brushless - 10 year motor warranty after registration
- Wireless mixing - whether on the scaffold, in the shell or in the
- 2-speed gear for high torque and mixing power
- Speed electronic for material- & application-oriented work
- Ergonomic handle with soft grip for comfortable work
- Adapted for an upright and back-friendly working position
- Durable and robust aluminium gear housing
- With soft start for a comfortable & splash-free start
- Robust stirrer holder with M14 thread
- Incl. 1x stirrer (Ø 120 mm)
- Supplied without battery and charger (sold separately)



Technical Data

Logistic Data

- Product weight (kg)	3.75
- Gross weight (kg)	6.56
- Dimensions single packaging	423 x 313 x 260 mm
- Pieces per export carton	2 Pieces
- Gross weight of export carton	13.8 kg
- Dimensions export carton	660 x 457 x 270 mm
- Container quantity (20"/40"/40"HC)	680 1436 1688



Available as special accessories



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory