



Einhell

PROFESSIONAL



Cordless Planer

TP-PL 18/3 Li BL - Solo

Item No.: 4345405

Ident No.: 21013

Bar Code: 4006825672718

The Einhell Professional Cordless Planer TP-PL 18/3 Li BL - Solo is a powerful tool for DIY enthusiasts, capable of handling applications with a cutting depth of up to 3 mm. It's powered by the Einhell PurePOWER Brushless Motor, delivering more power and longer runtime. After online registration, you'll receive a 10-year warranty for the motor. The large blade shafts ensure excellent planing results, and the sturdy aluminum base plate provides a flat working surface. This base plate also features three V-grooves for easy chamfering. The package includes a parallel guide, folding depth stop, and two TCT reversible blades. Battery and charger are not included.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Brushless motor - more power and longer running time
- PurePOWER Brushless - 10 year motor warranty after registration
- Powerful hand planer with high cutting depth
- Large cutter block for optimal planing results
- Two-sided selectable chip ejection for flexible working
- Solid aluminium footplates for flat work results
- Base plate with 3 V-grooves for easy chamfering of edges
- Simple, visible adjustment of chip depth
- Protection of workpiece and knife thanks to automatic park shoe
- Parallel guide for straight and precise planing work
- Rebate depth stop for easy production of heels
- Suction adapter for connecting Einhell wet/dry vacuums
- Ergonomic handle for fatigue-free working
- Comfortable, safe handling thanks to soft grip
- Incl. 2x long-life TCT planning knives (reversible knives)
- Recommended for optimum results: 2.5 Ah battery and larger
- Supplied without battery and without charger (sold separately)




Technical Data

- Planing width	82 mm
- Planing depth	3 mm
- Rebate Depth	25 mm

Logistic Data

- Product weight (kg)	2.63
- Gross weight (kg)	3.91
- Dimensions single packaging	345 x 170 x 255 mm
- Pieces per export carton	4 Pieces
- Gross weight of export carton	16 kg
- Dimensions export carton	360 x 350 x 532 mm
- Container quantities (20"/40"/40"HC)	1600 3192 4020



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery
Item No.: 4511489
Bar Code: 4006825638578



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2 HM-Wendemes. 5,5x82,0x1,1 Elektrohubel-Zubehör
Item No.: 49568315
Bar Code: 4009315683157
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

Battery-Running-Times

One Battery for All	planing ¹ (m)
1.5 Ah	19
2.0 Ah	26
2.5 Ah	32
3.0 Ah	38
4.0 Ah	50
5.2 Ah	65
6.0 Ah	78
8.0 Ah	100

For best performance select a battery with at least 2.5 Ah

Test setup:

1) softwood - spruce wood