

ETHOS 8380 SPECIFICATION

Earth Resistance Tester

| | | |
|-------------------------------|-------------------------|---------------|
| Model | | |
| Earth Resistance (Ω) | $\Omega \sim 20\Omega$ | $\pm(2\%+10)$ |
| | $\Omega \sim 200\Omega$ | $\pm(2\%+3)$ |
| | $0 \sim 2000\Omega$ | $\pm(2\%+3)$ |
| AC Earth Resistance (V) | $0 \sim 200V$ | $\pm(1\%+4)$ |
| | Frequency: 50Hz/60Hz | |

Features

- Manual Range
- Auto Power Off
- Low Battery Indication
- Data Hold
- Data Storage
- LCD Backlight
- Full Icon Display
- Double Insulation Protection
- Contact Badness Indication
- Overload Indication
- Simple 2-Wires Testing
- Precision 3-Wires Testing

ETHOS
Test Instruments

Distributed by MTi

Email: enquiries.ethos@adivision.co.uk

Web: www.ethos-instruments.co.uk