


IMPORTANT - PLEASE READ

- a) This product **MUST BE EARTHED** in accordance with the current IEE wiring regulations, where appropriate.
- b) Do not fit onto recently plastered walls.
- c) Read the general instruction procedure before commencing installation.
- d) If unsure of the installation please consult a skilled person (electrically).
- e) **CLEANING:** polish only with a soft clean dry cloth. **USE NO FLUID.**

GENERAL INSTALLATION/CONNECTION PROCEDURE

- 1) Isolate mains supply from existing accessory by switching off the appropriate circuit at the consumer unit.
- 2) Remove retaining screws and carefully withdraw accessory from wall box to reveal connections at the rear.
- 3) Disconnect all cables noting their respective connections.
- 4) Unpack your new M2 Screwless accessory and unclip the face plate by inserting a screwdriver in the




- 5) Connect accessory with reference to diagrams shown for each accessory.
- 6) Check all connections thoroughly.
- 7) Fix interior mechanism to the wall box by using the two screws provided taking care not to trap any of the cables.
- 8) If wall decorations are complete then clip on decorative face plate. If decoration is still to be done then store face plate until completion.
- 9) Switch on mains supply at the consumer unit and check operation of accessory.


DISCLAIMER

This accessory must be installed in accordance with these fitting instructions. It should be fixed in the approved and conventional way to a solid or stud partition wall. Wallpaper/wallpaper paste of any sort should not continue beneath the plate towards the working parts of the accessory. It should not be used in areas of high humidity (bathrooms etc.) nor within reach of a water source. The accessory should be connected to a mains supply of the appropriate voltage (indicated on the product.) Care should be taken not to overload the accessory (maximum wattage indicated on the product/packaging.) If you are unsure consult a skilled person (electrically) before fitting. No liability can be accepted if the product is installed or used in any other way.


1 WAY SWITCH




2 WAY SWITCH




INTERMEDIATE SWITCH




13A 1 GANG SWITCHED SOCKET




13A 2 GANG SWITCHED SOCKET




5A 1 GANG SWITCHED SOCKET




13A 1 GANG SOCKET WITH USB OUTLET




13A 2 GANG SOCKET WITH USB OUTLET




FUSE CONNECTION UNIT




SWITCHED FUSE CONNECTION UNIT




20A SWITCH




45A SWITCH




COOKER CONTROL UNIT




DIMMER SWITCH/ FAN CONTROLLER



TV SOCKET



BT SOCKET



Normally a maximum of 5 telephones can be connected to one exchange line. Any sockets are connected in parallel, i.e Pin 1 to Pin 1; Pin 2 to Pin 2: etc.

Colour Code

Pin Colour

1 Green or Green/White

2 Blue or Blue/White

3 Orange or Orange/White

4 White or White/Orange

5 White or White/Blue

6 White or White/Green

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1

1 2 3 4 5 6

6 5 4 3 2 1