

# D7PSM22PX10HS

Sprecher and Schuh D7 Selector Switch 22.5mm Hangsell PK  
PLT STD BLK Knob 2 POS Maintain Switch 1NO



PUSHBUTTON AND PILOT LIGHTS

**sprecher+**  
**schuh**



<b>Component type</b>	Selector switch, complete
<b>Range</b>	D7
<b>Model</b>	N/A
<b>Product status</b>	Existing

The Sprecher+Schuh D7 line of operator control devices are a diverse range of 22.5mm mount pushbuttons, pilot lights, selector switches, emergency stops, ideal for use in applications requiring reliable performance. A modular design allows for easy configuration and assembly. Available in plastic and metal types, optional accessories include enclosures, legend plates, padlocks and colour caps.

<b>ELECTRICAL</b>	Type of control element	Short thumb-grip
	Number of contacts as normally open contact	1
	Type of electric connection	Screw connection
<b>CONSTRUCTION</b>	IP rating	IP66
	Colour button	White
	Material front ring	Plastic
<b>MECHANICAL</b>	Number of switch positions	2
	Switching function latching	No
	Spring-return	No
	Max. shock acceleration	100 g
	Max. vibration frequency, operational	2000 Hz
<b>PHOTOMETRIC</b>	Suitable for illumination	No
	<b>DIMENSIONS</b>	Hole diameter
<b>ENVIRONMENT</b>	Operating temperature	-25...70 °C

# D7PSM22PX10HS

Sprecher and Schuh D7 Selector Switch 22.5mm Hangsell PK  
PLT STD BLK Knob 2 POS Maintain Switch 1NO



PUSHBUTTON AND PILOT LIGHTS

sprecher+schuh

## DIMENSIONAL DIAGRAM

