

## Quick Overview

---

Combined RCD Polarity Socket Checker - 10, 15, 20, 25, 30, 35mA



## Features

---

### RCD Testers

#### NESCO RCD Checker

- Basic RCD and polarity socket tester
- Trip current settings 10, 15, 20, 25, 30, 35mA
- Gives true indication of RCD trip rate

## Details

---

Part No.	S-1602
Brand	Nesco
Unit Of Measure	Each
Carton Quantity	1
Compendium Page #	558

---