

PIXIE Smart Power Point

#SPO23BTAM



Basic operation

- 1 click to turn on/ off left and right outlets respectively.
- 4 clicks manual pairing
- 9 clicks reset device
- Press and hold left+right button for >12sec to activate/ deactivate child lock

Applications

Energy management control of appliances in kitchens and bathrooms, phone chargers, wall and floor lamps

Whats in the box

1 x Smart power point, 1 x PIXIE Ambience white faceplate, installation instructions


Accessories

PIXIE Ambience faceplates in Grey & Black. Also has 3 interchangeable faceplates designed to suit popular plate styles in gloss white and colours.



SCAN ME

Download the PIXIE and
PIXIE PLUS Apps



#SPO23BTAM

PIXIE Smart Power Point (GPO)



A smart socket outlet designed to operate as a standard 250V / 10A double wall socket and communicate with PIXIE devices via the centre mount Multifunction control. Interchangeable cover plates and caps available and comes with Bluetooth Mesh Technology, Groups, Scenes, Schedules, Timers.

Features

- Control the GPO via a standard push button action and PIXIE Apps
- Each socket individually controllable
- Schedule each socket individually
- The PIXIE multifunction control (middle button) will pair with all PIXIE devices, groups and scenes anywhere in the PIXIE enabled home.
- Designed with a Child lock function when operating with the PIXIE Plus app and activation /deactivation via front buttons
- Easy identification via colour-coded terminals for installation by authorised electricians
- Insulated screw caps for combination flat/Philips head screws

Electrical

Power Supply	250V AC @ 50Hz
Max loads	10A max.
Operating ambient min/max (°C)	0 to 40°
Typical wireless range	15 metres typical indoors **
IP Rating	IP20
Energy Monitoring	Per socket, in PIXIE Plus App
Compliance	AS/NZS 3112:2017



PIXIE Smart Power Point

#SPO23BTAM



Related products

PIXIE Touch Panel
#STP54BTAS



PIXIE Smart Dimmer
#SDD300BTAM




PIXIE Smart Timer
#STS600BTAM




PIXIE 600W Switch
#SWL600BTAM



Dimensions



The Middle button is a PIXIE multifunction control button. It can be paired with any PIXIE master device to achieve multiway control, or to configured to control a group or a scene with the PIXIE or PIXIE Plus app



Faceplate Options - Colours



Faceplate Included
Gloss White
Round, sunken buttons



Faceplate SPO23AG/BTP
Matt Gray
Round, sunken buttons



Faceplate SPO23AB/BTP
Matt Black
Round, sunken buttons

Faceplate Options - Design



Faceplate only
SPO23CW-BTP
White only

Styling characteristics appeal to home owners who like classic faceplates.



Faceplate only
SPO23IW-BTP
White only

Styling characteristics appeal to homeowners who like modern faceplates.



Faceplate only
SPO23EW-BTP
White only

Styling characteristics appeal to homeowners who like HPM™ faceplates.

SCAN ME



Download the PIXIE and
PIXIE PLUS Apps

